

WARRANTY AND MAINTENANCE SHEET

Before attempting assembly, examine the enclosed drawings; identify the various parts and their corresponding part numbers. Compare the parts and quantities with packing list, noting any discrepancies. The assembly drawings were designed to provide you with and easy to understand picture of the bleacher assembly. Should you have any difficulties in assembly, contact our customer service department at 1-800-527-7510.

IMPORTANT NOTICE

These bleachers have been designed and manufactured to meet NFPA National Fire Protection Association and CPSC Consumer Product Safety Commission Standards for Safety. <u>However, since local codes may vary, the purchaser of the product must be responsible for compliance with local or state codes pertaining to this product.</u> The manufacturer, distributor, or any of their representatives assume no liability for code compliance.

SURFACE PREPARATION

ALL bleachers **MUST** be installed on a solid, smooth and level surface. Manufacturer will not be responsible for any damage resulting from the use of this product on any irregular surface conditions. **ALL** bleachers with a top row seat over 30" from ground level **MUST** be anchored to a concrete pad or footer. Most local codes require permanent anchoring to concrete to meet wind load requirements. Please check your local codes. Bleachers with a top row seat less than 30" from ground level may remain portable however manufacturer strongly recommends attaching weather treated lumber Groundsills. Groundsills should be at least 2" x 6" lumber and attached with $\frac{3}{8}$ " x 1 ½" lag screws (not provided).

STORAGE

Assembled units shall be stored in usable position only, not tilted back on column. The manufacturer will not be responsible for damage or personal injury resulting from product being stored in any other position.

MAINTAINANCE

In order to assure continued spectator safety and comfort, an annual inspection of these bleachers is required. No warranties, specified or implied, will be honored on this product unless replacement parts are purchased from original manufacturer and unless inspection and maintainance records have been kept by the Owner. This annual inspection shall include, but is not limited to the following:

- 1. Bolt tightness (Bolts, nuts, set screws, etc).
- 2. Vertical and horizontal alignment of all component parts.
- 3. Any broken or damaged parts, whether from normal use or abuse.
- 4. End cap fit and condition (snug fit, unbroken condition).
- 5. Visual inspection of any and all welded connections.
- 6. Insure that the base angle is in full and continuous contact with supporting surface, i.e., turf, concrete, asphalt or grade.

WARRANTY

All bleachers shall carry, after proper assembly and under normal use for the type of structure, a five (5) year warranty against all defects in matierials and workmanship. In addition, all aluminum plank extrusions shall be covered by a one (1) year warranty against deterioration of anodized finish or loss of structural strength due specifically to constant exposure to changing weather and environmental conditions. Acts of vandalism or abuse shall render the conditions of these warranties null and void


Page 1 REVISED 9/17


STEP 1 FRAME ASSEMBLY

1. Place the long Cross Braces 81 1/2" and medium Cross Braces 75 3/4" and short Cross Braces 73 \(^7\)\(^8\)" together- flat side to flat side, then bolt the center hole using Bolt (ITEM DD), Washers (ITEM Z), Lockwashers (ITEM AA) and Hex Nut (ITEM BB) (see figure 2).

2. Attach Cross Braces to Frames (ITEM C) as shown in Figures 1 & 2.


3. Check frame for squareness and tighten all nuts and bolts.






Page 2

REV 9/15





- 1. **NOTE:** THERE IS A LEFT AND A RIGHT SIDE SUPPORT (**ITEM D**).
- 2. POSITION SIDE SUPPORTS (ITEM $\bf D$) AS SHOWN IN FIG 6 & 7. ONCE IN POSITION ON PLANKS, MARK LOCATION OF HOLES ON PLANKS.
- 3. DRILL A 3/8" DIA. HOLE IN THE 4 LOCATIONS YOU MARKED.
- 4. BOLT SIDE SUPPORT TO PLANKS AS SHOWN IN FIG 6 & 7. REPEAT ON OTHER SIDE OF BLEACHER.

STEP #7 BACK FENCE SUPPORT ASSEMBLY

1. BOLT THE BACK SUPPORT (ITEM E) TO EACH REAR RISER AS SHOWN IN FIG.-6.


Page 4 REV 6/16


STEP #8 SIDE FENCE ASSEMBLY

- 1. REFER TO FIG-8 AND INSTALL 11 TENSION BANDS (ITEM N) AND 2 BRACE BANDS (ITEM P) ATTACH THESE TO 2 RAIL ENDS (ITEM O) USING HARDWARE (ITEM V) AS SHOWN. NOTE: KEEP THE STRAIGHT SIDE OF THE TENSION BANDS-N ALL ON THE SAME SIDE OF THE FENCE FRAME. REPEAT ON THE SECOND SIDE FENCE FRAME REVERSING THE TENSION BANDS.
- 2. UNROLL THE 12 FOOT ROLL OF FENCE MATERIAL (**ITEM J**). MEASURE 6 FEET AND UNBEND TOP & BOTTOM OF A SINGLE WIRE TO BE REMOVED. IN A CIRCULAR MOTION REMOVE THIS SINGLE WIRE TO CREATE 2 6 FOOT PIECES OF FENCE SEE FIG 9.
- 3. NOW ON A FLAT SURFACE, PLACE ONE OF THE 6' SECTIONS OF FENCE MATERIAL OVER THE FENCE FRAME AS SHOWN IN FIG-10.

 4. INSERT A TENSION BAR (ITEM K) INTO THE CHAIN LINK BY WEAVING IT THROUGH THE FENCE PARALLEL TO THE FRAME TUBE. PLACE TENSION BAR (ITEM K) SO THAT YOU WILL HAVE APPX 3/4" WHEN YOU CUT OFF EXCESS MATERIAL. REPEAT PROCEDURE ON OPPOSITE SIDE OF FENCE FRAME (SEE FIG.-10).

 5. USING BOLT CUTTERS CUT FENCE OUTSIDE OF TENSION BARS; CUT EVERY OTHER WIRE AND BEND EXPOSED WIRE AROUND TENSION BAR (SEE FIG-11).





STEP#9 **BACK GUARD RAIL & SIDE FENCE PANEL INSTALLATION** 1. Slide 4 Tension Bands (ITEM N) on each of the Guard Rail Tubes (ITEM H). 2. Bolt Tension Bands (ITEM N) to the Back Fence Supports (see Detail A). Do Not Tighten At This Time 3. Place the Side Fence Panels in place on the outside of supports and insert **BACK FENCE** Guard Rail Tubes (ITEM H) into Rail Ends (ITEM O) (see Details B & C). **SUPPORT DETAIL A** 4. Square up 2 Tension Bands (ITEM N) with Side Fence Support and mark hole placement. Drill $\frac{3}{8}$ " Dia. hole in Support and attach Tension Bands (see Detail D). (P) G DETAIL C (V)SIDE FENCE (G) **SUPPORT** 0 SEE NOTE #4 (Must Drill Holes) DETAIL B


Page 7

DETAIL D

rev. 9/15

STEP #10 INSTALLING REAR GUARD RAIL WIRE

- 1. Unroll the 42" width roll of wire. The length of the wire will be longer than you need and will need to be shortened. Do not shorten until one end is attached and you know exactly where to shorten.
- 2. Weave the Tension Bar through one end. Now bolt in place on one end of the Side Panel using 3 Tension Bands (ITEM N), and Bolt w/Nut (ITEM V). Be sure bolts are facing away from the seating area.
- 3. With one end now bolted, stretch the wire to the other end. Determine where the Tension Bar needs to be placed and weave it through the wire.
- 4. Unbend the top and bottom of a single wire in a circular motion remove the wire to obtain proper length.
- 5. Stretch the wire and bolt this end using the Tension Bands and fasteners as on the other end.
- 6. Tie the top and bottom of the wire to the guard rail tubes using the aluminum Wire Ties (ITEM T) spaced approximately 18" apart.



Page 8 10/11

5 ROW - 70 SEAT - 21' BLEACHER PARTS LIST

| ITEM | DESCRIPTION | QTY | ITEM | DESCRIPTION | QTY |
|----------------|------------------------------|--------|------|--------------------------------|------------------|
| \overline{A} | 21' ANODIZED SEAT PLANK | 5 EA | L | HARDWARE PACK | 1 EA |
| В | 21' MILL FINISH FOOT PLANK | 8 EA | (H. | ARDWARE PACK CONTENTS) | |
| С | 5 ROW BLEACHER FRAME | 4 EA | M | STEEL POST CAP | 2 EA |
| D | SIDE FENCE SUPPORTS L & R | 1 PR | N | TENSION BANDS 1 5/8" | 30 EA |
| Е | BACK FENCE SUPPORTS | 4 EA | 0 | RAIL ENDS 1 5/8" | 4 EA |
| F | X BRACES (14 pcs) | 1 SET | Р | BRACE BANDS 1 5/8" | 4 EA |
| G | SIDE FENCE FRAME | 1 SET | Q | PLANK END CAPS | 26 EA |
| Н | BACK GUARD RAIL TUBES 21' | 1 PR | R | RISER TABS | 8 EA |
| J | CHAINLINK FENCE 42" x 25' | 1 ROLL | S | BOLT CLIPS | 104 EA |
| J | CHAINLINK FENCE 48" x 12' | 1 ROLL | Т | ALUM WIRE TIES | 100 EA |
| K | TENSION BARS | 6 EA | U | CARRIAGE BOLT 5/16" x 1 1/4" Z | ZINC 104 EA |
| | (2 each Short & 4 each Long) | | V | CARRIAGE BOLT 5/16" X 1 1/4" v | w/NUT GALV 34 EA |
| | | | W | WASHER 5/16" | 20 EA |
| | | | X | LOCKING FLANGE NUT | 112 EA |
| | | | Υ | HEX BOLT 5/16" x 1" | 8 EA |
| | | | Z | WASHER 3/8" | 94 EA |
| | | | AA | LOCK WASHER 3/8" | 43 EA |
| | | | BB | HEX NUT 3/8" | 43 EA |
| | | | CC | HEX BOLT 3/8" x 1" | 8 EA |
| | | | DD | HEX BOLT 3/8" x 1 1/4" | 35 EA |
| | | | EE | SELF DRILLING SCREW #8 | 104 EA |

