

JAYPRO SPORTS

BOX LACROSSE GOAL WITH FLAT BACKSTAY, LG-44B LIST OF MATERIALS

<u>Y.</u>
4
8
8
8
2
4
2
2

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: 5 mm & 6 mm ALLEN WRENCH (PROVIDED)

- 1) POSITION BACKSTAYS (1) ON A LEVEL SURFACE AND JOIN REAR OF GOAL USING THE MOUNTING PLATE (5) AND FASTENERS AS SHOWN IN THE ILLUSTRATION. DO NOT TIGHTEN FASTENERS.
- 2) SLIP UPRIGHTS (6) ONTO THE HUB OF EACH BACKSTAY THEN PLACE THE CROSSBAR (7) INTO POSITION. THE NET TIE RAILS FACE TOWARD THE REAR OF THE GOAL.
- 3) SQUARE THE GOAL, CHECK FOR 48" INSIDE DIMENSION FOR THE GOAL FACE. THEN, FULLY TIGHTEN ALL HARDWARE.
- 4) CHECK HARDWARE BEFORE EACH USE TO ENSURE FASTENERS ARE FULLY TIGHTENED.