

SVB28

BOUNDARY KIT INSTALLATION



Customer Service
(800) 247-7668

1. Please read all instructions before proceeding.
2. Layout the boundary rope use the drawing on the bottom of these instructions for the dimensions. Make sure the volleyball posts are centered.
3. The optimum location for the ground anchors is in each corner and directly below volleyball net.
4. Insert the steel rod in the eyelet end of the anchor and turn in a clock wise rotation with a downward pressure. The top of the anchor eyelet must be 5"-6" below the finished grade of the sand. When back filling the sand stretch the retainer hook onto the boundary rope and crimp on if desired.

