

WINDSCREEN INSTALLATION INSTRUCTIONS

For best results, read completely before starting

Congratulations! You have purchased a quality windscreen/fence cover product that will enhance the appearance of your venue for years to come!

Proper installation is extremely important and will provide the maximum in benefits:

- Give a professional, wrinkle-free appearance that will enhance the look of the venue
- Maximize the life and durability of the windscreen cover
- Ensure that the windscreen panels fit the dimensions of the fence area to be covered (rather than the panels coming up too short once they are installed).

Installation Procedure:

1. Start at one end of the fence area to be covered. Lay out full panel along area to be covered. Attach top corner grommet to the fence with tie wrap (or cord). Then, attach along top, pulling cover taut with each grommet attachment for about 10'.

Tip 1: Use a few “S” hooks to temporarily hang the panel on the fence. By “lifting” the panel, it lessens the weight and makes it easier to attach and tighten the tie wrap at the grommet.

IMPORTANT! Attach at every grommet. Do not skip grommets. Attachment at all grommets distributes the force when there is a high wind load. Using fewer grommets for attachment results in more load on attached grommets and greater chance of ties breaking. When windscreen cover breaks loose and whips against the fence, it can be damaged beyond repair in a few hours.

Tip 2: Attach tie wrap to the fence in the direction the panel is being pulled (rather than slightly backward). As the tie is tightened, it will pull the cover taut. Make sure tie is secure, but don't over tighten tie wraps (Tightening the tie wraps too much might result in wrinkling of cover and insufficient room to straighten out panel). After panel is completely attached, ties can be tightened more, if necessary, to minimize any remaining wrinkles.

2. Go back to end and from top-to-bottom attach vertical edge to the fence all the way to the bottom, again pulling taut as each tie is secured.
3. Continue attachment along bottom for about 10' pulling cover taut and making it as wrinkle free as possible.
Tip 3: If two or more people are working on the panel, have one person begin attachment at the top and the second person at the bottom, working about 10' behind the first.
4. After the first 10' of windscreen is attached at top and bottom, go back to the top and attach along the next 10', pulling taut.
5. Continue top/bottom attachment until panel is completely in place.
6. Continue installation with remaining panels using the same procedure.

Tip 4: Don't install on a windy day. Wind will complicate installation.



Example of windscreen not installed properly



Example of properly installed windscreen