



# HEDGEHOG TACKLER

## PAD INSTALLATION GUIDE

Model #: HH4R



## ITEM CHECKLIST

### HEDGEHOG PADS - X4



### HEDGEHOG TACKLER FRAME - X1



## STEP 1

Grab first pad and fit onto the current vertical leg of the frame. When sliding the pad on, leave about 4 inches of space between the bottom of the pad and the center point of the frame. Fasten the straps around the legs of the frame and loop back through the attached "D" rings making sure not to tighten them up. The straps will be tightened once the rest of the pads are attached to the frame. If the pad is too difficult to slide onto the post we recommend using a product such as 409 to wet and allow the foam to slide on more easily.





## STEP 2

Tip the tackler over to bring a new leg up into the vertical position and repeat the previous step. Repeat this process until you have one vertical post left without a pad.



## STEP 3

Tighten the straps on each of the attached pads until the pad is nearly touching the center of the frame (approx. 2" of space between center and foam). Make sure the straps are hand tightened and taut. When complete you should have only the one vertical leg left without padding.



## STEP 4

Slide last pad onto the remaining vertical leg. Attach straps around the straps from the other pads and cinch tight. Tuck the straps into the space between the pads and frame.



## COMPLETE

Your Hedgehog 4 Way Tackler is ready to use!



## QUESTIONS OR FEEDBACK

Phone: 800.438.6028

Email: [customerservice@fisherathletic.com](mailto:customerservice@fisherathletic.com)



**\*\*MAKE SURE ALL STRAPS ARE TIGHTENED BEFORE USING\*\***