



RIB COMBO
INSTALLATION
INSTRUCTIONS

This is the ultimate in wrap-around rib and lower back protection, ideal for quarterbacks and wide receivers. See diagram below for proper installation.



1. Align and mark the four brass eyelets of the RIB COMBO on top of the shoulder pad shell.



2. Drill holes (if necessary), and slide RIB COMBO between plastic shells and cushions of the shoulder pad.



3. Put screws through grommets and into plastic. Insert screw assembly as shown.