

## ASSEMBLY INSTRUCTIONS FOR S PADS



**PLEASE READ S PAD ASSEMBLY CAREFULLY!**  
Please note: Instruction show the S2 pad cover, but assembly is the same for S1 and S2 covers.

The Interior Front Cover has a pocket that the S spring slides into.

Slide the pad fully into the pocket.



There are 2 yellow Velcro flaps that wrap around the S Spring.



Wrap the yellow flaps around the S Spring tight.



Position the back S pad over the S Spring and align the Velcro straps at the top.



Pull the Velcro straps tight and Velcro together, there are 4 straps in total.



Don't forget the final strap at the bottom



The finished interior covers "sandwich" together incasing the S Spring from player contact.



Place your exterior S cover (S1 or S2) over the interior covers. If it is cold the cover will be rigid and hard to fit, so best to do this with the cover out in the sun.



Pull on the vinyl cover so that it fits tight on the interior covers. "Feel" the cover around the curves of the padding.



The zipper starts at the bottom of the pad.



SO THAT YOU DON'T RIP THE ZIPPER OUT OF THE COVER PLEASE USE 2 PEOPLE FOR THIS STAGE. Have one person gathers the vinyl together as the other person starts zipping.



Again, pull and adjust the cover so that it fits into the foam.



Finish by closing the Velcro on the zipper seam.



PLEASE NOTE WHEN YOUR SEASON IS OVER

1. REMOVE THE PADS
2. LET PADS DRY OUT
3. WRAP THEM IN PLASTIC (GARBAGE BAG)
4. STORE IN A DRY AREA

WHEN YOUR SEASON STARTS MAKE SURE THE PERSON ASSEMBLING THE PADS ON THE SLED READS THESE DIRECTIONS. THANK YOU, WE APPRECIATE YOUR BUSINESS.