

### NOTICE

Whenever installing a glass backboard to a new or existing structure with three or four attachment points, attachment locations must always be coplanar. If any attachment point is more than 1/16" out of plumb from the other attachment points it is recommended to make adjustments to the structure before proceeding with installing the backboard. If adjustments can't be made to the structure, shim the attachment point/s with washers provided to ensure all attachment points are coplanar. Failure to correct the attachment points can lead to strain on the backboard resulting in breakage of the glass bank.

