

GROUND SLEEVE INSTALLATION

NOTE: These instructions are simply a general guide, a local professional should be contacted familiar with the soil conditions in your area.

INSTALLATION:

1. Locate the placement for the Ground Sleeves.
(Location must be doubled checked for accuracy)
2. Dig holes, 24" square and 30" deep, as shown.
3. Add approximately 6" gravel and a brick or block in the bottom to prevent Sleeve from later sinking and to add more stability.
4. Set the Ground Sleeve in the hole- flush with ground level.
5. Support in place, ensuring that the Ground Sleeve is properly plumbed.
6. Pour concrete to within 2.0" of the top of the Ground Sleeve and allow to cure properly before using.
(Keep Ground Sleeve Cap on during this to prevent concrete from entering Ground Sleeve)

