

DO NOT HANG ON CROSSBAR.
THIS IS DANGEROUS AND
MAY DAMAGE YOUR EQUIPMENT
THIS UNIT IS HEAVY, ALWAYS USE
AT LEAST TWO PEOPLE TO TRANSPORT
THIS GOAL

Jaypro Sports

976 Hartford Turnpike Waterford, CT 06385 USA (800)243-0533 (800)988-3363 Fax www.jaypro.com MODEL NO.:

LG-50

PRODUCT NAME: LACROSSE GOAL WITH FLAT BACKSTAY

DRAWN BY: JAC

2-11-04

JAYPRO SPORTS

LACROSSE GOAL WITH FLAT BACKSTAY, LG-50 LIST OF MATERIALS

PIECE NO.	PART NO.	DESCRIPTION	QTY.
1	LG505	FLAT BACKSTAY	4
2	HN265	RETAINING WASHER M10	8
3	HW2047	FLAT WASHER M10	8
4	HS287	HEX HEAD BOLT M10	8
5	LG5010	MOUNTING PLATE	2
6	LG5014	UPRIGHT	4
7	LG501	CROSSBAR	2
8	HS882	SOCKET HEAD SET SCREW M10X16	12
9	SR1727	GROUND ANCHOR 3/8" x 22"	6

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: 9/16" OPEN END WRENCH (2) OR ADJUSTABLE WRENCH (2)

- 1) POSITION BACKSTAYS (1) ON A LEVEL SURFACE AND JOIN REAR OF GOAL USING THE MOUNTING PLATE (5) AND FASTENERS AS SHOWN IN THE ILLUSTRATION. DO NOT TIGHTEN FASTENERS.
- 2) SLIP UPRIGHTS (6) ONTO THE HUB OF EACH BACKSTAY THEN PLACE THE CROSSBAR (7) INTO POSITION. THE NET TIE RAILS FACE TOWARD THE REAR OF THE GOAL.
- 3) SQUARE THE GOAL, CHECK FOR 72" INSIDE DIMENSION FOR THE GOAL FACE. THEN, FULLY TIGHTEN ALL HARDWARE.
- 4) ONCE THE GOAL IS IN ITS PLACE ON THE FIELD, ANCHOR IT USING THE THREE GROUND ANCHORS (9) PROVIDED.
- 5) CHECK HARDWARE BEFORE EACH USE TO ENSURE FASTENERS ARE FULLY TIGHTENED.