

BA187

Sharpshooter™ Ballcart



Customer Service
(800) 247-7668

| PARTS LIST | | | | | |
|------------|-----|-----------------------------|------|-----|----------------------------|
| Item | Qty | Description | Item | Qty | Description |
| A | 1 | Tall Frame Side | F | 12 | 1/2" Button Head Cap Screw |
| B | 1 | Short Frame Side | G | 2 | 1/2" Hex Nut |
| C | 1 | Long Horizontal Bar Bracket | H | 1 | 5/16" Allen Wrench |
| D | 2 | Long Horizontal Bar | I | 4 | Caster |
| E | 3 | Short Horizontal Bar | | | |

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
 - ◆ Read all instructions before proceeding.
1. Use *1/2" Button Head Cap Screws (F)* to install the three *Short Horizontal Bars (E)* between the *Tall Frame Side (A)* and *Short Frame Side (B)*. Hand tighten hardware. See Figure 1.
 2. Use *1/2" Button Head Cap Screws (F)* and *1/2" Hex Nuts (G)* to attach *Long Horizontal Bar Bracket (C)* to *Short Frame Side (B)*. Hand tighten hardware. See Figure 1.
 3. Use *1/2" Button Head Cap Screws (F)* to attach the *Long Horizontal Bars (D)* between the *Tall Frame Side (A)* and *Long Horizontal Bar Bracket (C)*. Hand tighten hardware. See Figure 1.
 4. Insert the *Casters (I)* into the bottom of *Tall Frame Side (A)* and *Short Frame Side (B)*. See Figure 1.
 5. Place assembled ball cart on a smooth flat surface. Use the *5/16" Allen Wrench (H)* to tighten all hardware.
See Figure 1

Figure 1

