

## **ProCage™ Premium Sock Net Installation Instructions**



NOTE: Netting is pillow-case style allowing the net to slide over the top of the protective screen frame. One side has a sewn sock and the other has an opening.

1. Position netting with sewn sock portion pulled away from the side with the opening.
2. Keeping both sides separated, slide the netting over the top of the frame.
3. After sliding netting over frame, pull the sock through the opening at the center of the frame. Perimeter of sock can be secured with lacing twine or cable ties (optional)
4. Netting can be secured around bottom of frame with cable ties or lacing twine.



Trigon Sports International, Inc.  
488 Cumberland Street  
Memphis, TN 38112  
888-313-1303  
[www.trigonsports.com](http://www.trigonsports.com)