

POWERNET®

INSTRUCTIONS

1007 | BATTING TEE

EASY SETUP & EASY TEARDOWN

PARTS LIST

- (1) RUBBER TOP
- (1) BASE

1.



1. Insert tee top into base about halfway down.



2.



2a. Loosen wing nut at red clamp.



2b. With one hand, hold tee above red clamp and with the other hand, push red clamp down to extend the legs.



2c. Tighten wing nut.

3.



3. To adjust the height of your tee, loosen black side knob to pull up on post and tighten to secure.

NOTE: Leaving some of the tee top extended provides the most flexibility for your tee. Most height adjustments can be made as described in Step 3.

RUBBER TOP:

Removable & height adjustable

RUBBER TOP HOLDER:


NOT adjustable
DON'T twist
May cause breakage

KNOB:

Adjusts height

WINGNUT:

Adjusts base



WARNING:

- Only used as a tee for hitting balls.
- Use adult supervision and follow instructions when using and setting up the tee.
- Frequent use and/or abuse will eventually strain the tee and will cause breakage.

BASEBALL/SOFTBALL



Our Vision

PowerNet Inc. is dedicated to providing quality products at affordable prices. Our goal is to develop the skills of the young, old, seasoned and professional athletes through training, reps and practice. Further building confidence leading to consistent winning performance.

Using PowerNet's equipment indoors and outdoors creates better players. PowerNet gives the opportunity to have the accessibility to practice anywhere with our nets and equipment. We believe that using the process of integrating practice in your daily lives allows you to mold the next generation into professionals & professionals into icons through their performance. Separating the best players from the good by providing life skills for the future.

Thank you for choosing Powernet

CHECK OUT OUR VIDEO INSTRUCTIONS AT:



POWERNET,INC



WWW.POWERNETINC.NET

Other Items Available:



Sweet Spot Bat



Micro Heavies

***Out Work!
Out Play!***



POWERNETBASEBALLNET



@POWERNET_BASEBALL



POWERNET,INC



WWW.POWERNETINC.NET

13959 CENTRAL AVENUE • CHINO • CA • 91710 • 909.203.5495