


Parts List:

- (2) SIDE BASE LEGS
- (1) MALE/FEMALE BAR (M/F)
- (1) MALE/MALE BAR (M/M)
- (2) LOWER FIBERGLASS POLES
- (2) UPPER FIBERGLASS POLES
- (1) NET



POWERNET®

Out Work! Out Play!

Assembly Instructions for PowerNet Pitch-Thru Screen



1. To build the base, attach M/F bar to any side base leg.



2. To this bar, attach the M/M bar.



3. To complete the base, attach the second base leg.



4. Insert 1 lower fiberglass pole into one side base leg. Repeat on other side.



5. Slip one net sleeve over one lower fiberglass pole. Repeat on other side.



6. Insert 1 upper fiberglass pole into one lower fiberglass pole. Repeat on other side.



7. Connect the white loop on net to silver attachment point on upper fiberglass pole. Repeat on other side.



8. Attach velcro straps to center bar on base.



9. Attach bottom net loop on side base hooks for both sides.

PowerNet Inc. Premium Sports Net
13959 Central Ave - Chino, CA 91710