


## **ASSEMBLY INSTRUCTIONS FOR 16A4201 REBOUNDER**

Unpack all parts and check for damage that may have occurred during shipping. If damage has occurred, notify Kwik Goal immediately. Lay out all parts. Remove all cardboard and packaging immediately. Wet or damp packaging may damage contents.





## Replacement Parts

3A401 Includes net and bungees

JZ253 Includes one complete set of bolts, nuts, and snap buttons

Go to kwikgoal.com for additional product information.





Go to kwikgoal.com for additional product information.