




# HOME RANGE GOLF NET

## GETTING STARTED



Thank you for choosing the SKLZ Home Range Golf Net. We are dedicated to providing you with the best tools and instruction possible to help you prepare for your sport. If there is anything else we can do to help, don't hesitate to send us an email at [help@4implus.com](mailto:help@4implus.com) or give us a call toll-free **1-800-446-7587**.

### BEFORE YOU BEGIN:

- Read all instructions carefully before using. Failure to do so may result in injury or damage to the product.
- Always check for wear and tear before use. If any is found, do not use the product.
- If you are missing any of the Home Range Golf Net components, please contact Implus customer service toll free at **1-800-446-7587**.
- Adult assembly required.

### ⚠️WARNING:

**PHYSICIANS WARNING:** Not all exercise equipment and programs are suitable for everyone. It is recommended that you consult your physician before using this equipment or beginning this or any other exercise program.

- Home Range Golf Net is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.
- To avoid pinching, use caution when assembling the push-button tubing.
- Regularly check for wear and tear. Stop using Home Range Golf Net if any part of it breaks. Failure to do so could result in injury.
- When in use, make sure the Home Range Golf Net is set up in a clear area to avoid injury.
- When using the Home Range Golf Net, others should stay clear of the area to reduce the risk of injury.
- Any alteration of this product or its components will result in a disclaimer of liability.

### ⚠️CAUTION:

- Keep away from fire and heat sources.
- Do not leave Home Range Golf Net outdoors for extended periods of time.
- When done, disassemble Home Range Golf Net and store after use. Do not leave Home Range Golf Net outdoors.
- When in use, make sure the Home Range Golf Net is set up in a clear area to avoid damage to property.

### 1-YEAR LIMITED WARRANTY

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise, and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email [help@4implus.com](mailto:help@4implus.com) or call toll-free 1-800-446-7587.**

Made in China. ©2021 Implus Footcare, LLC. Manufactured and distributed by Implus Footcare, LLC: 2001 T.W. Alexander Drive, Box 13925, Durham, NC 27709-3925. SKLZ is a trademark or registered trademark of Implus Footcare, LLC in the U.S. and/or other countries.

## IN THE BOX



**A** Base Frame Center Back Bar



**B** Base Frame Angled Back Bars (2)



**D** Lower Fiberglass Poles (4)



**E** Top Fiberglass Poles (2)



**C** Side Bars (2)



**F** Dual Return Net



**G** Carry Bag

## GETTING STARTED



### Step 1


Lay out all 5 base frame pieces.

Connect back bar of base frame by inserting the angled back bars (B) to each side of the center back bar (A) via push pins.



### Step 2

Connect each side bar (C) to the angled back bars (B) via push pins.



### Step 3

Connect two lower fiberglass poles (D), repeat step for opposite side.

Note: Top Fiberglass Pole (E) will be inserted in following steps.



### Step 4

Layout net (F) with the return net side facing down, and the SKLZ logo sleeves facing up. Slide each sleeve over the connected Fiberglass Poles (D) assembled in step 3.

Insert connected fiberglass pole into the base frame. Repeat on opposite side.

Note: Once the first side is inserted the second side will need a slight bend to insert fiberglass poles into the base frame.



### Step 5

Connect top fiberglass poles (E) to each side.

Grab white loop at the top corner of the net (F), and attach white loop to the top of fiberglass pole (E). Repeat on opposite side.

Note: Bend pole inward if you cannot reach top of pole.



### Step 6

Attach bottom of net (F) via black loop to side bar of base frame (C). Repeat on opposite side.