


ASSEMBLY INSTRUCTIONS FOR 10B4606 ANCHOR WEIGHT FOR PORTABLE ONLY SHELTERS

- 1. Unpack all parts and check for damage that may have occurred during shipping. If damage has occurred, notify Kwik Goal immediately. Lay out all parts. Remove all cardboard and packaging immediately. Wet or damp packaging may damage contents.
- 2. Read through entire instruction before beginning assembly and installation.

<u>Parts</u>



Hardware (Part# JZ278)

7/16" X 5-1/4" Hex Bolt (Part# TZ375)	(2)
7/16" X 6" Hex Bolt (Part# TZ380)	(2)
7/16" Lock Nut (Part# TZ47)	(4)
7/16" Flat Washer (Part# TZ171)	(2)
7/16" Large Flat Washer (Part# TZ422)	(6)

Assembly Tools

5/8" Wrench

Ratchet with 5/8" Socket





THIS UNIT MUST BE ANCHORED ACCORDING TO THESE INSTRUCTIONS AT ALL TIMES


AWARNING THIS EQUIPMENT MUST BE STORED IN A SECURED, SHELTERED AREA WHEN NOT IN USE OR IN THE THREAT OF HIGH WINDS. ANY WEATHER DAMAGE TO THIS EQUIPMENT WILL NOT BE COVERED UNDER KWIK GOAL'S PRODUCT GUARANTEE. DO NOT LEAVE THIS EQUIPMENT UNATTENDED.

> 140 Pacific Drive Quakertown, PA 18951 800-531-4252 Kwikgoal.com © 2020 Kwik Goal Ltd.




AWARNING IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY

- 1. Lifting and moving heavy field equipment can be dangerous if not done properly. All Kwik Goal shelters must be moved by qualified personnel who are experienced in moving large, heavy field equipment.
- 2. A minimum of four qualified, experienced people are required to move shelter.
- 3. Do not attempt to lift or move shelter in windy conditions.
- 4. Shelters must not be left unattended and unsecured.
- 5. Shelter must be on level, flat ground at all times.
- 6. Use extreme caution when pushing shelter. Excessive force can overturn shelter. Always push at lowest point on shelter frame possible.
- 7. Do not push shelter directly from the front to rear or rear to front. Push from end to end.




NEVER LEAVE SHELTERS UNATTENDED AND UNSECURED

3. Assemble anchor weights as shown below. Note: Do not overtighten hardware.



AWARNING THIS EQUIPMENT MUST BE STORED IN A SECURED, SHELTERED AREA WHEN NOT IN USE OR IN THE THREAT OF HIGH WINDS. ANY WEATHER DAMAGE TO THIS EQUIPMENT WILL NOT BE COVERED UNDER KWIK GOAL'S PRODUCT GUARANTEE. DO NOT LEAVE THIS EQUIPMENT UNATTENDED.



Go to Kwikgoal.com for additional product information.

AWARNING THIS EQUIPMENT MUST BE STORED IN A SECURED, SHELTERED AREA WHEN NOT IN USE OR IN THE THREAT OF HIGH WINDS. ANY WEATHER DAMAGE TO THIS EQUIPMENT WILL NOT BE COVERED UNDER KWIK GOAL'S PRODUCT GUARANTEE. DO NOT LEAVE THIS EQUIPMENT UNATTENDED.