



QUICKSTER
REP NET

SKLZ®

INSTRUCTION MANUAL
INCLUDES:
» QUICKSTER REP NET
» Carry Bag
» Ground Stakes (4)

Thank you for choosing SKLZ QUICKSTER REP NET. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to drop us an email (customerservice@sklz.com) or give us a call (**1-877-225-7275**).

BEFORE YOU BEGIN:

- » Read all setup and usage instructions carefully before using. If the setup and/or instructions are not followed correctly, it could result in injury or damage to the product.
- » Adult assembly recommended.
- » Make sure you have all of the QUICKSTER REP NET components. Please contact SKLZ customer service toll free at **1-877-225-7275** if you are missing anything.

⚠ WARNING:

Regularly check for wear and tear. Stop using QUICKSTER REP NET if any part of it breaks. Failure to do so could result in injury.

QUICKSTER REP NET is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.

QUICKSTER REP NET cannot catch all batted balls. Set-up in a clear area to avoid damage to property.

Do not climb or hang on the QUICKSTER REP NET.

Keep away from fire and heat sources.

Not suitable for children under 3 years of age.

LIMITED WARRANTY

REGISTER YOUR PRODUCT AT SKLZ.COM TO ENSURE WARRANTY COVERAGE, GET NEW PRODUCT INFORMATION AND SPECIAL DEALS FROM SKLZ

Pro Performance Sports (PPS) / SKLZ warrants to the original consumer purchaser of any PPS/SKLZ product it manufactures that the product will be free of defects in materials or workmanship for 90 days (unless specified in alternate warranties) from the date of purchase. If defective and purchased from a retail store, return the product along with receipt to the retail store where the product was purchased. If the item was purchased from PPS/SKLZ, return the product along with the packing slip (proof of purchase) postage prepaid to the address below for replacement consideration. Label: Attn: Returns

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise. Only valid in the USA. All returns sent to PPS/SKLZ require a Return Merchandise Authorization number (RMA). For returns to PPS/SKLZ and for all other Customer Service inquiries, please email customerservice@sklz.com or call toll free, 1-877-225-7275 for a return authorization number for any exchange.


Made in China. ©2013 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ, SKLZ Pro Grade, SKLZ Chrome and Sport-Brella are registered trademarks of Pro Performance Sports, LLC., its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

IDEA SUBMISSION
If you have an idea for a new and innovative sports training product, visit sklz.com to submit your concept. Some restrictions may apply.

PATENT #:
US and Foreign patents pending.

QUICKSTER REP NET

QUICKSTER PITCH RETURN IS PERFECT FOR:
» **BASEBALL** » **SOFTBALL** » **LACROSSE**




QUICKSTER PITCH RETURN PARTS:


A NET WITH BALL COLLECTION




B BASE FRAME



C TENSION-TITE ARM POLE (2)



D CROSS BAR



E GROUND STAKES (4)



STEP 1
BASE FRAME & TENSION-TITE™ ARM POLE

- NOTE – Base Frame and Tension-Tite arm poles come pre-attached by elastic cords.
1. Lay out one Arm Pole (C) and link together to form a straight pole. Repeat with second Tension-Tite Arm Pole.
 2. Lay out Base Frame (B) and link the frame together. Make sure to secure the poles with the push buttons.
 3. Lay out cross bar (D) and link together.
 4. Slide tube on cross bar over base frame. Rivet will keep cross bar in place.
- NOTE –The slight bowing on the Base Frame is a normal part of the Tension-Tite system design.
5. Slide the Tension-Tite Arm Poles into each side of the Base Frame.
- NOTE - Ensure arm poles are fully inserted. Failure to do so may result in damage to the QUICKSTER.

STEP 2
CONNECT THE NET TO THE FRAME










1. Unfold the Net (A) and slide the pin at the top of one corner of the net into the top of the Tension-Tite Arm Pole. Make sure that the QUICKSTER logo on the net is facing away from the frame. Repeat on the other side.
 2. Attach bottom Net loop attachments to the plastic post hooks on each side of the base frame.
 3. Clip back of net to Arm Pole. Follow illustration #3 for placement.
 4. Clip webbing straps to the base frame.
 5. Wrap the bottom of the net under the back base frame and Velcro around the side base frame.
- NOTE: Check the frame to make sure it is securely and fully assembled with the net before securing to the ground.

STEP 3
SECURE THE QUICKSTER

- Place QUICKSTER in the desired location and ensure it is on level ground. Secure frame with included Ground Stakes. Ground Stakes can be secured with hand, foot or mallet.
- NOTE: Do not use Ground Stakes on the back of the base frame. Poles will bend and tension system will not function properly.
- NOTE: Care should be taken when pressing in the ground stakes. Poles can be bent if driven too far into the ground or hard surface.
- CAUTION: Make sure the QUICKSTER is secured into the ground before play. During play make sure that the Ground Stakes are secured as a loose Ground Stake may cause injury.

STEP 4
BUCKET RECOMMENDATIONS

- QUICKSTER® REP NET funnels the balls into the central hole. Place a bucket (not included) or other capture device to collect the balls.



STORING YOUR QUICKSTER


- ▲ WARNING:**
- QUICKSTER is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.
- Hold one pin in one hand and one Tension-Tite Arm Pole in the other while pulling the pin out. Repeat on the other side. Remove the net loop attachments from each side of the frame. If needed, air dry the net before you fold and place it into the carry bag.
- Pull the Tension-Tite Arm Poles out of each side of the base frame and unlink and fold them down to store.
- Fold up and place into the carry bag. Remove the Ground Stakes and place them into the carry bag.
- NOTE: Store Tension-Tite Arm Pole in the carry bag with the round tops facing away from each other.
- Unlock the push buttons on the Base Frame to unlink the frame. Fold and store in carry bag.

PERFECT FOR PRACTICE WITH:

CATAPULT

SOFT TOSS MACHINE AND FIELDING TRAINER

- » Adjustable height and distance
- » Automatically tosses balls every 8 seconds
- » Use regulation baseballs for hitting training during practice or pregame warm-up
- » Use 9" plastic balls for pop fly practice
- » Use regulation baseballs to practice footwork and glove-hand ball transfer



1. Place CATAPULT behind crossbar as shown and align the ball return hole with the top of the ball feeder.
2. Use the Velcro strap on the REP NET ball return hole to attach the net to the CATAPULT ball feeder.



VISIT SKLZ.COM FOR INSTRUCTIONAL VIDEO AND CONTENT