



WARNING: READ CAREFULLY BEFORE INSTALLING MINI-GOAL. SERIOUS INJURY CAN OCCUR WITH IMPROPER INSTALLATION AND USE.



THIS

- NEVER ALLOW A CHILD TO INSTALL. ONLY RESPONSIBLE, AUTHORIZED ADULTS SHOULD INSTALL AND REMOVE.
- INSTALL ONLY FROM A STURDY SURFACE.
- KEEP FACE SAFELY BELOW THE BOTTOM OF THE MINI-GOAL.
- LEVER ARM IS SPRING-LOADED AND CAN CAUSE INJURY IF NOT CONTROLLED.
- NEVER ALLOW DUNKING AS GOAL MIGHT BECOME DETACHED FROM RIM AND FALL ON PLAYERS.
- PRACTICE SAFE LIFTING TECHNIQUES WHEN INSTALLING.
- HEIGHT OF INSTALLER WILL DETERMINE SUITABILITY OF STANDING SURFACE.



NOT THIS

Installation Procedure

Photo 1: Remove two wingnuts from folding frame and reinstall wingnuts with frame in the 90° extended position.

Photo 2: Remove the T-Screw that locks the rim in the storage position and reinstall with rim in the play position.

Photo 3: Disengage the lever arm from the locked/stored position.




Photo 4: Pull the rod down about two inches, rotate 180° to the left and secure in the open position. **You are now ready to lift the MINI-GOAL and attach it to a stable, properly supported, indoor basketball goal.**

Photo 5: Loosely position the metal frame portion of the MINI-GOAL onto the top of the 10' rim while standing on a sturdy step ladder, step stool or chair.

Photo 6: Position the MINI-GOAL so the two hooks on the metal frame engage the inside of the 10' rim.

Photo 7: Release the lever arm from the open position and slide the rod upward to trap the rim. Make sure the rod is fully engaged in the hole in the top tab. Align the MINI-GOAL so it is square with the court.

Photo 8: Complete the installation by taking a firm grip of the lever arm, rotate to the right and engage in the locked position. **Keep a firm grip on the lever arm when engaging or releasing from the locked/storage position. If accidentally released, the lever arm could rotate backwards with great force. Keep all parts of the body clear of the rotating lever arm.**



CAUTION: The intended use of the MINI-GOAL is the shooting, not dunking, of a regulation junior basketball (circumference 27 1/4") by youngsters, ages 5-12, while the GOAL is attached to a stable, properly supported, indoor basketball goal. Only responsible, authorized adults should install and remove the MINI-GOAL. Precaution should be taken to install the MINI-GOAL correctly so as to eliminate the danger of it falling, which could cause personal injury or result in damage to the MINI-GOAL. The MINI-GOAL should be removed and properly stored after each period of use, so as to prevent any unsupervised or unintended usage. **The MINI-GOAL is NOT designed to support a person hanging from the net or rim. Dunking could cause personal injury or result in damage to the MINI-GOAL.**

WARRANTY DISCLAIMER: No guarantee of warranty, express or implied, is made in connection with either the intended or unintended use or effects incidental to such use, handling or possession of the MINI-GOAL. Seller and manufacturer make no warranty of merchantability regarding the MINI-GOAL. The MINI-GOAL is not warranted as suitable for any purpose particular to the buyer. The suitability of the MINI-GOAL for any purpose particular to the buyer is for the buyer, in his sole judgment, to determine. Seller and manufacturer assume no responsibility for the selection or furnishing of goods suitable to the individual needs and purposes of any particular buyer. In no event shall the seller or manufacturer be liable for direct to consequential injury, loss or damage to person or property arising out of the intended or unintended use, handling or possession of this product. Liability, if any, shall be limited to the price paid for any MINI-GOAL proved to be defective.