

INSTALLATION INSTRUCTIONS FOR

OPTIONAL RECHARGEABLE BATTERY SUPPLY

www.sportablescoreboards.com

INSTALLATION INSTRUCTIONS

RECHARGEABLE BATTERY SUPPLY

Weight:

weight = approximately 5 lbs

Mounting Requirements:

Inside the shot clock in the bracket secured with 2 screws to the back of the shot clock.

INSTALLING THE RECAHRGEABLE BATTERY SUPPLY

1. To remove the front with the digits and horn attached. Remove the screw holding the face on with the z rails.
2. You will only need to remove the left side with six (6) screws and the bottom with six (6) screws.
3. Then gently remove the face and set aside.
4. Install the battery by bending the tap that will be bent back over the top of the battery to secure it in place.
5. Slide the battery in to the bracket and bend the tap back ensuring not to touch the terminals of the battery.
6. Connect the wires supplied with the option kit they are color specific black to the Negative and red to the positive
7. Locate the connections on the board on the back of the face and connect according as indicated on the board.
8. Reinstall the face ensuring not to pinch any wires slide the face under the right and top z brackets that were left on the board.
9. Replace the z rails and screws to secure the face to the shot clock.