

LIMITED WARRANTY

One Year Limited Warranty: We warrant the device against defects in materials and workmanship under ordinary consumer use for one year from the date of original retail purchase. During this warranty period, if a defect arises in the device, and you follow the instructions for returning the device at <http://www.chaheati.com/customer-services/return-exchanges>, we will at our option, to the extent permitted by law, either (i) repair the device using either new or refurbished parts, (ii) replace the device with a new or refurbished device that is equivalent to the device to be replaced, or (iii) refund to you all or part of the purchase price of the device. This limited warranty applies, to the extent permitted by law, to any repair, replacement part or replacement device for the remainder of the original warranty period or for ninety days, whichever period is longer. All replaced parts and devices for which a refund is given shall become our property. This limited warranty applies only to hardware components of the device that are not subject to accident, misuse, neglect, fire, or other external causes, alterations, repair, or commercial use.



chaheati.com


OFFICIAL LICENSED PRODUCT
ROLLER DERBY SKATE CORP.
401 Zion Hill Rd.
Atglen, PA 19310


For all inquiries please call:
Chaheati™ Company
217.324.3961 ext. 110 or 119

Chaheati™ Trademarks used
under license to Roller Derby



11.1 BATTERY / CHARGER INSTRUCTIONS





To Charge the Battery

1. Plug the Block Charger into an A/C wall socket.
2. Plug the cord that is attached to the Block Charger into the Battery's charging port.
3. A red light on the Block Charger will appear and turn green when fully charged. *The Battery takes about 3-1/2 hours to fully charge. Battery must be fully charged before use.*¹

To Plug in the Battery


On the right side of the product (either the Heated Chair or Heated Add-on) you will find the power-station for the Battery.

- A Black Pouch: Holds the Battery
- A Black Power Cable: Plugs into the Battery

Plug Black Power Cable fully into the Battery's charging port until it clicks.

Additional Features of 11.1 Maxx Battery

1. Battery has a 1.0A USB port for charging cell phones or tablets.
IMPORTANT: 1.0A USB port is **ONLY** for charging cell phones & tablets
2. USB port is located on side of battery where AC charger plugs into battery.
3. Please keep in mind when using the 1.0A USB port, the length of charge time will be reduced.



To Use/Turn On the Battery²

1. Find the Chaheati™ Smart Controller Button (see illustration) located on right side of either Chair or Add-On.
2. Hold down the Smart Controller for 2-3 seconds.
3. When turned on, Smart Controller Button will display a RED light representing the highest setting.

To Change Heat Settings²

1. Single click the Smart Controller Button to scroll to next heat setting of WHITE, (medium) and once more for lowest setting of BLUE. Continue toggling Smart Controller Button until desired setting is reached.

To Turn Off the Battery

1. Hold down the Smart Controller Button until light goes OFF.