


Proper Floor Sleeve Measurement

*Do not measure
cover plate*



*Measure the
distance between
the red arrows
for accurate
dimension*