




All Kwik Goal products carry a **Lifetime Guarantee**. For help with guarantee issues, visit kwikgoal.com and click on the **Lifetime Guarantee** logo or contact customer service at 1-800-531-4252.


ASSEMBLY INSTRUCTIONS FOR 2B2 PORTABLE FUTSAL SOCCER GOAL

1. Unpack all parts and check for damage that may have occurred during shipping. If damage has occurred, notify trucking company immediately. Lay out all parts. Remove all cardboard and packaging immediately. Wet or damp packaging may damage contents.
2. Read through entire instruction before beginning assembly and installation.
3. If goal is to be used in a portable application continue to step 4. If goal is to be used in a more permanent application skip steps 4 through 6 and begin assembly with step 7.


Post (2)
(Part# UZ510)




Rail w/ swage (2)
(Part# UZ509)



Base (2)
(Part# UZ527)




Rail w/o swage (2)
(Part# UZ493)




Ground Anchor (4)
(Part# TZ150)




Net Fastener (1)
(Part# VZ229)




Net (1)
(Part# 3B1)




Rubber Pad (5)
(Part# VZ188)



4. Assemble rails, bases and posts as shown.




5. Attach net to goal using net fastener, provided. Be sure to cut net fastener into 9"-10" pieces to ensure 2" overlap.




6. Use ground anchors to fasten goal to playing field as shown.


NOTE FOR INDOOR USE: Rubber pads can be added to bottom of goal by peeling off paper to expose adhesive. Place rubber pads on post and rails at locations shown.




7. Assemble rails, base and post as shown.




8. Weave assembled parts onto net as shown. Be sure to note the location of the top corner net tag.





9. Connect rails, posts and bases as shown.



10. Weave base through net and attach to rail as shown.



11. Disconnect post from goal and weave through net as shown. Reconnect post to base and rails as shown.



12. Repeat step 10 and 11 to attach net to opposite side of goal.

13. Use ground anchors to fasten goal to playing field.

NOTE FOR INDOOR USE: Rubber pads can be added to bottom of goal by peeling off paper to expose adhesive. Place rubber pads on post and rails at locations shown.

