




MIDWEST RAKE®

Mailing Address:
P.O. Box 1674
Warsaw, IN 46581-1674

Phone: 844.SEYMOUR
Fax: 574-267-8508
www.SeymourMidwest.com

Shipping Address:
2666 S. Country Club Rd.
Warsaw, IN 46580

Landscape Rake Assembly Instructions




Tools Needed for Assembly:

- 7/16" wrench (two)


Parts Shipped with Unit:

- Head
- Aluminum handle with grip (not shown)
- Wrap-around brace (set of 2)
- Bolt bag for braces



Assembly Instructions for Handle:

1. Insert flat-tipped end of handle into channel-shaped crossbar.
NOTE: This may be a tight fit requiring working the handle back and forth.
2. Align holes and insert middle sized bolt. Do not tighten until all hardware is in place.



Wrap-Around Brace Instructions:

1. Align holes of flat end of braces with holes on rake head, as shown, and insert the two shortest bolts.
2. Align holes of wrap-around end of braces with the handle, as shown, and insert the longest bolt.
3. Start all loc nuts on bolts. Use wrenches to tighten, being careful not to over-tighten. Over-tightening may result in crushing the handle, thereby compromising its strength.

FULL WARRANTY

All Midwest Rake products carry a full warranty against manufacturer defects in quality and workmanship. Products which have been abused or worn out from normal use are excluded from this warranty. We reserve the right to replace or issue credit on an individual basis.

REPLACEMENT PARTS LIST
See Reverse Side

PK90078
5/28/14

LANDSCAPE RAKE REPLACEMENT PARTS LIST

SP10000	Head – 24”
SP10001	Head – 30”
SP10002	Head – 36”
SP10003	Head – 42”
SP10004	Head – 48”
SA20000	Handle -- 66” blue powder coated aluminum w/red grip
SA20001	Handle – 66” blue powder coated aluminum w/green grip
SA20194	Handle – 66” yellow powder coated aluminum w/black grip
SA30001	Braces – wrap-around (set of 2)
SA60000	Bolt Bag: 4 bolts, 4 loc nuts
SP50000	Grip – 5” red vinyl
SP50002	Grip – 5” black vinyl
SP50003	Grip – 5” green vinyl