

E49720 – Wireless Starter System; 1.0 Customer Instructions

Wireless Starter System

The wireless starter system works with the Halo Electronic Starting Device. The Halo connects to this system wirelessly using a RF signal.

Features:

- 50-Watt Speaker (+90dB)
- Powered by 12V Battery
- Recharge battery with included charging cable
- Finish Lynx ® compatible timing system port
- Connects wirelessly to the Halo Electronic Starter Device

Included:

- Wireless Starter System
- Rain Cover
- 12V Battery
- Charging Cable
- Protective Soft Carrying Case
- Durable, wide base Tripod

Care Instructions:

- Keep the Wireless Starter System dry.
- Fully charge battery before putting it into storage.
- It is recommended to recharge battery approximately every 4 weeks, or to keep the unit plugged in while in storage.

WARNING

Risk of electricution when charging the unit. Inspect charging cable for bare wires before use.

Hearing damage risk: speaker produces +90dB. Do not stand directly in front of speaker. Wear ear protection to prevent hearing damage.

Crushing injuries can result if unit tips over. Securely attach unit to tripod.


Risk of fire, explosion, or burns.
Unit contains a 12V lead acid battery.
Store unit in a dry location between -40F - 110F.

Copyright © 2021 by Litania Sports Group, Inc. All rights reserved.



01/07/2021 Customer Instructions





⚠ WARNING: Cancer and Reproductive Harm – For more information go to www.p65warnings.ca.gov



Changing the 12V Battery

1. Remove the six Phillips head screws from the rear cover plate.




Rear Cover Screw (6x)

2. Carefully slide tray with the electrical components out of the housing.



3. Remove the two Phillips head screws to take out the bracket that holds the battery in place. Black cable to black terminal and red cable to red terminal.



4. Replace battery bracket and bracket screws. Do not overtighten the screw.



Copyright © 2021 by Litania Sports Group, Inc. All rights reserved.

5. Slide tray with electrical components back into the housing and replace rear cover screws. Do not overtighten the screw.





E49720 – Wireless Starter System; 1.0 Customer Instructions

FCC Compliance Statement

CAUTION: The manufacturer is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Product Name: Gill Wireless Starter System

Product Model: E49720

Manufacturer:

Litania Sports Group, Inc. sales@gillathletics.com

601 Mercury Drive <u>www.gillporter.com</u>

Champaign, IL, 61822

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.