



Please Read Carefully Before Use

WARNING: Must be 18 years of age or older to use this product. Children under 18 should be supervised by an adult.

WARNING: Use guy ropes in breezy or windy conditions to prevent personal injury or damage to Pod.

WARNING: Do not use near open flame or other heat sources.

WARNING: Do not sleep in tent.

CONTENTS:

- (1) SportPod™
- (8) Ground Stakes
- (8) Sand Bags
- (4) Guy Ropes
- (1) Carry Bag

IMPORTANT:

- **Set up your SportPod™ at home before your first use** to familiarize yourself with set-up.
- **Do not force the zipper pulls.** Your Pod has been packed for some time. The zippers will become easier to pull over time as the fabric relaxes.

For folding instruction video: visit anthem-sports.com/foldscreenroompod
(or see reverse side for folding diagram)


ScreenRoomPod™



ScreenRoomPod™ Folding Instructions


1

Set up one person on each side. _____




2

Lay the SportPod™ on its side in the open position. _____



3

Both people take a top corner and fold it down to the opposite corner. _____




4

Make sure the steel wire on the long ends line up and are not twisted. _____



5

Tuck in the floor and top. _____



6

Fold the SportPod™ flat. _____




7

One person holds the SportPod™ as shown. _____



8

Take one corner and connect it to the opposite corner. _____



9

Slide the top corner to the left. _____



10

Fold in the circles that are formed on each side. _____



For folding instruction video: visit anthem-sports.com/screenroompod

If you have trouble folding your SportPod™, please contact the Anthem Sports customer service team for help at 800-688-6709, Monday-Friday 8:30am-5:00pm EST.