



Warning

- Keep fingers away from hinges and joints
- To be used for restrianing Soccer Balls only
- Not a toy, do not climb or swing on net
- Must be used with adult supervision
- Must be either Staked or Weighted down using BowBags (not supplied)
- Don't drag. To move net, use two people.




Play Anywhere. - Play NOW!






on the ground.



2. Open one half of Frame resting it 3. Lift side Frame of Net until hinge locks (clicking sound)



1. Place double hinge on ground with Net

spread out away from you. Pull one side


4. Repeat on other half of Frame, All 4 Hinges should be locked. Lay the Frame on the ground with the Rubber Feet down.



Join Black Poles together (see A) Take 2 of the 4 poles and slot them into the 2 rear Tubes.



6. Take the 2 remaining Poles and feed them down the orange 'front posts' sleeves and slot them into the front tubes.



7. Next the 2 front Net Loops and place over the tops of the front Poles.

8. Repeat with rear Loops holding Poles and Net firmly

9. Finally take black Loops (A) and place under Rubber Feet. (B) Stake the Net on Grass or use Bowbags on Turf (not supplied)

Rubber Foot

1 year limited Manufactures Warranty on Manufacturing defects only. 30 day money back guarantee. For a full description of Warranty-Guarantee-Terms & Conditions, See www.thebownet.com

Triad Sports Group LLC.4690 Calle Quetzal Camarillo, California 93012 866.950.NETS