

# QUICKSTER° **SPORT NET**



### **INSTRUCTION** MANUAL

» Sport Net

» Carry bag

Thank you for choosing SKLZ Quickster Sport Net. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to send us an email (customerservice@sklz.com) or give us a call (1-877-225-7275).

### **BEFORE YOU BEGIN:**

- » Adult assembly required.
- » Make sure you have all of the Sport Net components. Please contact SKLZ customer service toll free at 877-225-7275 x128 if you are missing anything.
- » Read all setup and usage instructions carefully.
- » When done, disassemble Sport Net and store after use. Do not leave Sport Net outdoors.
- » Regularly check for wear and tear. Stop using net if any part of it breaks. Failure to do so could result in injury.
- » Keep away from fire and heat sources.

### **AWARNING:**

- » Quickster Sport Net is under tension when set up. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.
- » Do not climb or hang on the Quickster Sport Net.
- » When in use, make sure the Quickster Sport Net is set up in a clear area to avoid injury and/or damage to property.
- » To avoid pinching, use caution when connecting the push-button tubing.




**VISIT SKLZ.COM FOR INSTRUCTIONAL VIDEO AND CONTENT** 

### QUICKSTER SPORT NET PARTS:

A – Net

B – Base Frame



C – Tension-Tite™ Arm Pole (2)

D – Ground Stakes (4)






E – Removable Pitching Target








QUICKSTER

SPORT NET IS PERFECT FOR:

» BASEBALL » SOFTBALL » FOOTBALL

» SOCCER » LACROSSE



# STEP 1 BASE FRAME & TENSION-TITE™ARM POLE

NOTE: Base Frame and Tension-Tite arm poles come preattached by elastic.

Layout one Tension-Tite Arm Pole (C) and link together to form a straight pole. Repeat with second Tension-Tite Arm Pole. Layout Base Frame (B) and link the frame together. Make sure to secure the poles with the push buttons.

NOTE: The slight bowing on the Base Frame is part of the Tension-Tite system design.

Slide the Tension-Tite™ Arm Poles into each side of the Base Frame

NOTE: Ensure arm poles are fully inserted. Failure to do so may result in damage to the Sport Net.

# 1.

### STEP 2

### CONNECT THE NET TO THE FRAME

- 1 Unfold the Net (A) and make sure that the top Quickster logo on the net is facing away from the frame. Connect the net loops on the bottom of the net to each side of the frame.
- 2 Slide the pin at the top of the net into the top of the Tension-Tite Arm Pole. Repeat on the other side.

NOTE: Check the frame to make sure it is securely and fully assembled with the net before securing to the ground.






STEP 3

### ATTACH PITCHING TARGET (OPTIONAL)

Unfold the Target (E) and find the top straps (these have adjustment buckles on them). Attach hook of the top strap through the fabric loop at the top left corner of the net, repeat on the other side. Take one of the bottom straps of the target and hook through fabric loop on the bottom corner of the net, repeat on the other side.



# STEP 4 SECUI

SIDE

ONLY secure stakes where

### EP 4

### SECURE THE QUICKSTER TO THE GROUND

Place Quickster in the desired location and ensure it is on level ground. Secure frame with included Ground Stakes. Ground Stakes can be secured with hand, foot or mallet.

NOTE: Do not use Ground Stakes on the back of the base frame. Poles will bend and tension system will not function properly.

NOTE: Care should be taken when pressing in the ground stakes. Poles can be bent if driven too far into the ground or hard surface.

CAUTION: Make sure the Quickster is secured into the ground before play. During play, make sure that the Ground Stakes are secured regularly as a loose Ground Stake may cause injury.



Remove the pitching target and place into the carry bag. Remove the ground stakes and place them in to the carry bag.

WARNING: Sport Net is under tension when assembled. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.

Hold one pin in one hand and one Tension-Tite arm pole in the other while pulling the pin out. Repeat on the other side. Remove the net webbing loops from each side of the frame. If needed, air dry the net before you fold and place it into the bag. Pull the Tension-Tite arm poles out of each side of the base frame and unlink and fold them down to store.

NOTE: Store Tension-Tite arm pole in the carry bag with the round tops facing away from each other. Unlock the push buttons on the base frame to unlink the frame. Fold and store in carry bag.

SKLZ offers a limited 1-year warranty for this product, visit SKLZ.com for full warranty details and to register your product.

## PERFECT FOR PRACTICE WITH:


# **QUICKSWING® PX4**

4-WAY GRAVITY-DROP AND REBOUNDER SYSTEM


- » Auto-feeds 12 baseballs or 8 softballs every6, 8 and 10 seconds for quick hands and reaction training
- » Use with practice or regulation balls
- » The ultimate system for developing fast hands, sharp reaction times, and solid mechanics
- » Four configurations: Auto-feed gravity drop, rebounder for tee hitting, rebounder angled for soft toss and rebounder angled for turn around double play







simulation



Rebounder for angled

soft toss



Rebounder for angled turnaround double play

### **5-POSITION BRUSH TEE**

TRUE-FLIGHT ULTRA-DURABLE BATTING TRAINER

- » Standard tee with brush top and height adjustment
- » Positions for 5 different zones across the plate  $\,$
- » Helps build confidence and hand-eye coordination in youth players
- » 15" base, with telescoping tee arm
- » Brush top provides more realistic ball flight, feel and feedback — get cleanly through the ball without any shock to the bat or hands
- » Sets up quickly and easily

