

PORTABLE WATER CHILLER



PORTABLE WATER CHILLER

ASSEMBLY OF YOUR SPORTS COOL - WATER CHILLER

- STEP 1)** Unpack the Cart (*item A*) and attach the Water Manifold (*item C*) to the cart using the Tension Bands (*item G*) and bolts, washers and locknuts (*items N,O,P*) as shown in diagram.
- STEP 2)** Secure Water Tank (*item D*) to Cart using the Tie Down Strap (*item J*); locate as shown in diagram.
- STEP 3)** Connect the Male Hose from Tank to the Female Hose on the Water Manifold.
- STEP 4)** Now connect the Female Hose from Tank to a Sanitary water supply hose.

OPERATING INSTRUCTIONS

- 1) Fill Chiller Tank to full capacity with ice. As water flows through the Copper Coil Assembly (*item H*) it will become chilled. Replace ice in Tank as needed.
- 2) **CAUTION - DANGEROUS DISEASES CAN BE TRANSMITTED BY DRINKING CONTAMINATED WATER.** CLEAN AND PROPERLY SANITIZE AND FLUSH SYSTEM AFTER EACH USE. SANITIZE DRINKING WANDS AFTER EACH USE.
- 3) Drain all water and remove lid from Chiller Tank when not in use.
- 4) Drain water from drinking wands when not in use.

ITEM	DESCRIPTION	QTY	PART #
A	2 WHEEL HYDRATION CART	1 EA	ZDRINK2WHL
B	MALE HOSE CONNECTOR	1 EA	ZX3920106
C	WATER MANIFOLD	1 EA	ZSPCDMA
D	WATER CHILLER TANK ASSEMBLY	1 EA	ZSPCCOIL2
E	FEMALE HOSE CONNECTOR	1 EA	ZX3920104
G	TENSION BAND	2 EA	ZX0900098
H	COPPER COIL - ONLY	1 EA	ZX3920045
J	TIE DOWN STRAP	1 EA	ZX3900040
K	COIL HOSE ASSEMBLY	6 EA	SPCHOSE
L	WATER WAND #6	6 EA	ZX3920080
M	POLY TRIGGER VALVE	6 EA	ZX3920038
N	HEX BOLT 1/4" X 1"	2 EA	Z041250100
O	FLAT WASHER 1/4"	4 EA	Z070025Z/P
P	LOCK NUT 1/4"	2 EA	Z060250XXX

PORTABLE WATER CHILLER

