

SOCCER GOAL WHEEL CARRIAGE INSTRUCTIONS



Step 1: Face both tires inward toward the carriage. Slip both bolts inside the wheels. Fasten each wheel to the carriage using the 4 axle bolts. Ensure wheels are installed. Make sure valve stems are facing outward. Tighten all bolts securely.



Step 2: Cut 48 inch Velcro Strap material into four 12 inch long pieces. Insert the Velcro Strap, fuzzy side up, into the slots of each end of the carriage as shown. Let approximately 2 inches of Velcro hang past the bracket.



Step 3: Position the wheel carriage assembly under the backstay as shown. Wrap the Velcro straps around the backstay tube on both ends. The wheel carriage assembly may be positioned anywhere along the length of the backstay tube.



Step 4: Use two people to lift the backstay of the goal off the ground. Reposition the goal as needed.

Pro-Bound Sports LLC
428 Old Highway 40, Dorrance, KS 67634

Phone: (800) 525-8580
E-mail: sales@proboundsports.com

CAUTION: Remove The Wheels Prior To Using The Goals For Play.