


FEATURES



ULTRAK

Ultrak 330

Time/calendar display: Hour, minute, seconds, month, date and day

Stopwatch 1/100 sec. for 30 min. 1sec. up to 24 hours

Changeover between 12 and 24 hour indications

Note: Depress A to select the desired mode

NORMAL MODE

TIME

Hour, minute and seconds are displayed

5:30³⁶

ALARM

Keep C depressed to read the alarm time
(This illustration shows that the alarm keeps at 6:30 AM)

6:30^A

ALARM ON/OFF

Alarm engaged
Keep B and C depressed at the same time

6:30^A

2 8³⁶

10:09³⁶

22:09³⁶

CALENDAR

Month/Date
Keep B depressed, month, date, and day are displayed

12 or 24 HOUR INDICATION

Select 12 or 24 hour cycle option when setting normal time, hour by advancing figure to "A" / "P" for 12 hour mode or "H" for 24 hour mode


STOPWATCH MODE

- Depress A to activate this mode
- Button B : Start/Stop ; Button C : Split/Split release/Reset
- Depress C to reset the stopwatch to "0 00 00" before using the stopwatch

Accumulated elapsed time measurement : B-B-B-B-C



Split time measurement: B-C-C-B-C




Measurement between two competitors : B-C-B-C-C



Depress A to return to the normal mode

TIME/CALENDAR SETTING MODE

- Depress A three times to activate this mode
- Depress C to select the digits to be adjusted (flashing)



- Depress B to reset the seconds to "00" or to set the other digits
 - Keep B depressed to advance the digits quickly
 - Notes : When the seconds count any number from "30" to "59" and B is depressed one minute is added
- Depress A to return to the normal mode

ALARM SETTING MODE

HOURL

Depress A twice to activate this mode
Depress B to advance the hour

3:30^A

MINUTE

Depress C to activate this mode
Depress B to advance the minute
Depress A to return to the normal time mode

3:30^A