



## Please Read Carefully Before Use

**WARNING:** Must be 18 years of age or older to use this product. Children under 18 should be supervised by an adult.

**WARNING:** Use guy ropes in breezy or windy conditions to prevent personal injury or damage to Pod.

**WARNING:** Do not use near open flame or other heat sources.

**WARNING:** Do not sleep in tent.

### CONTENTS:

- (1) SportPod™.
- (8) Ground Stakes.
- (8) Sand Bags.
- (4) Guy Ropes.
- (1) Carry Bag.

### IMPORTANT:

- **Set up your SportPod™ at home before your first use** to familiarize yourself with set-up.
- **Do not force the zipper pulls.** Your Pod has been packed for some time. The zippers will become easier to pull over time as the fabric relaxes.

**For folding instruction video: visit [anthem-sports.com/foldactionpod](http://anthem-sports.com/foldactionpod)**  
(or see reverse side for folding diagram)


## ActionPod™



# ActionPod™ Folding Instructions

1

Lay the SportPod™ flat. \_\_\_\_\_




2

Collapse the SportPod™ so that the long edges are touching. \_\_\_\_\_




3

Hold the SportPod™ on the top corners as shown. Push the top toward the bottom. \_\_\_\_\_



4

Curl the top of the SportPod™ under. \_\_\_\_\_



5

Fold the circles (formed from curling the SportPod™ in Step 4) toward the middle and flat on the ground. \_\_\_\_\_



**Folding instructions: Visit [anthem-sports.com/foldactionpod](http://anthem-sports.com/foldactionpod)**

If you have trouble folding your Pod, please reach out to the Anthem Sports customer service team for help at 800-688-6709.