



## Please Read Carefully Before Use

**WARNING:** Must be 18 years of age or older to use this product. Children under 18 should be supervised by an adult.

**WARNING:** Use guy ropes in breezy or windy conditions to prevent personal injury or damage to Pod.

**WARNING:** Do not use near open flame or other heat sources.

**WARNING:** Do not sleep in tent.

### CONTENTS:

- (1) SportPod™.
- (8) Ground Stakes.
- (8) Sand Bags.
- (4) Guy Ropes.
- (1) Carry Bag.

### IMPORTANT:

- **Set up your SportPod™ at home before your first use** to familiarize yourself with set-up.
- **Do not force the zipper pulls.** Your Pod has been packed for some time. The zippers will become easier to pull over time as the fabric relaxes.

**For folding instruction video: visit [anthem-sports.com/foldonepod](https://anthem-sports.com/foldonepod)**  
(or see reverse side for folding diagram)

## OnePod™



# OnePod™ Folding Instructions

**1**

Lay the SportPod™ flat.



**2**


Tuck the floor in and fold the side down so that the SportPod™ is flat.

Collapse the SportPod™ so that the long edges are touching.



**3**

Hold the SportPod™ on the top corners as shown. Push the top toward the bottom.



**4**

Curl the top of the SportPod™ under.



**5**

Fold the circles (formed from curling the SportPod™ in Step 4) toward the middle and flat on the ground.



**Folding instructions: Visit [anthem-sports.com/foldonepod](http://anthem-sports.com/foldonepod)**

If you have trouble folding your SportPod™, please contact the Anthem Sports customer service team for help at 800-688-6709, Monday-Friday 8:30am-5:00pm EST.