



Please Read Carefully Before Use

WARNING: Must be 18 years of age or older to use this product. Children under 18 should be supervised by an adult.

WARNING: Use guy ropes in breezy or windy conditions to prevent personal injury or damage to Pod.

WARNING: Do not use near open flame or other heat sources.

WARNING: Do not sleep in tent.

CONTENTS:

- (1) SportPod™.
- (8) Ground Stakes.
- (8) Sand Bags.
- (4) Guy Ropes.
- (1) Carry Bag.

IMPORTANT:

- **Set up your SportPod™ at home before your first use** to familiarize yourself with set-up.
- **Do not force the zipper pulls.** Your Pod has been packed for some time. The zippers will become easier to pull over time as the fabric relaxes.

For folding instruction video: visit anthem-sports.com/foldsolopod
(or see reverse side for folding diagram)


SoloPod™



SoloPod™ Folding Instructions

1

Lay the SportPod™ flat.




2

Collapse the SportPod™ so that the long edges are touching.



3

Hold the SportPod™ on the top corners as shown. Push the top toward the bottom.



4

Curl the top of the SportPod™ under.



5

Fold the circles (formed from curling the SportPod™ in Step 4) toward the middle and flat on the ground.



For folding instruction video: visit anthem-sports.com/foldsolopod

If you have trouble folding your Pod, please reach out to the Anthem Sports customer service team for help at 800-688-6709.