



Please Read Carefully Before Use

WARNING: Must be 18 years of age or older to use this product. Children under 18 should be supervised by an adult.

WARNING: Use guy ropes in breezy or windy conditions to prevent personal injury or damage to Pod.

WARNING: Do not use near open flame or other heat sources.

WARNING: Do not sleep in tent.

CONTENTS:

- (1) SportPod™.
- (1) Clear Door (1) Screen Door.
- (8) Ground Stakes.
- (8) Sand Bags.
- (4) Guy Ropes.
- (1) Carry Bag.

IMPORTANT:

- **Set up your SportPod™ at home before your first use** to familiarize yourself with set-up.
- **Do not force the zipper pulls.** Your Pod has been packed for some time. The zippers will become easier to pull over time as the fabric relaxes.

For folding instruction video: visit anthem-sports.com/foldteampod

(or see reverse side for folding diagram)


TeamPod™



TeamPod™ Folding Instructions


1

Set up one person on each side.




2

Lay the TeamPod™ on its side in the open position.



3

Both people take a top corner and fold it down to the opposite corner.




4

Make sure the steel wire on the long ends line up and are not twisted.



5

Tuck in the floor and top.




6

Fold the TeamPod™ flat.



7

One person holds the TeamPod™ as shown.



8

Take one corner and connect it to the opposite corner.



9

Slide the top corner to the left.



10

Fold in the circles that are formed on each side.



For folding instruction video: visit anthem-sports.com/foldteampod

If you have trouble folding your Pod, please reach out to the Anthem Sports customer service team for help at 800-688-6709.