


# Installing Bases: the MarkSmart™ Way ...with Pre-Assembled Base Foundations (PABF)

Steps to Fast, Easy, Accurate Base Installation:

1. Determine the appropriate Field Layout. See Table below. All infield distances are measured from the point of Homeplate to the outer corner of 1st and 3rd base and center of 2nd base.

## IMPORTANT FIELD DIMENSIONS

(A)	(B)	(C)
Base Distances	HP to Pitch Plate	HP to 2nd Base
90 ft	60 ft 6 in	127 ft 3-3/8 in
70 ft	50 ft	99 ft
60 ft	46 ft	84 ft
50 ft	38 ft	70 ft 8-1/2 in




You may also need...




Feathered Base Plugs  
Set of 3  
#BBBLPLUGPK




Dig-out Tool  
#BBDIGOUT



2. Dig 20" diameter hole no less than 10" deep for each base. Create a firm foundation using crushed stone or Baseball Clay at bottom of base. We suggest a minimum of 1 to 1-1/2" of material. Foundation should be tamped and leveled.



3. Place PABF anchor on leveled material. Center of PABF should be 7.5" from String Line and 7.5" toward Homeplate. Recheck and make sure PABF is level



4. Backfill hole around PABF up to field level. Note: Top of Anchor should be 1" below field level. Rubber or Feathered Base Plugs are recommended if Base is not in place.

